

## Kit Content

	36rxn	
Syringe	36	set
Elution Tube	36	pcs
AT10025 Cartridge	36	set
AT10025 Column Set	36	set
AT10025 Tip Set	36	set
EtOH Tube	36	pcs
Sample Tube	36	pcs
Carrier RNA	200	µg
Proteinase K	11	mg
Buffer AE	1.5	ml
Buffer TVL	10	ml

## Kit Storage

Upon arrival,


1. **Carrier RNA** and **Proteinase K** should be stored at **-20°C upon arrival** for long term storage.
2. Cartridge and consumables, please store at 15-25 °C.

## Kit Preparation


1. **Prepare 10 mg/ml Proteinase K**  
For 11 mg Proteinase K, please add 1.1 ml Buffer AE into tube and vortex thoroughly for dissolving. After dissolving into solvent, please store in 4°C for 6 month or -20°C for 1 year.
2. **Prepare 1 µg/µl Carrier RNA**  
For 200 µg Carrier RNA, please add 200 µl Buffer AE into the bottom of tube and mix thoroughly for dissolving. After dissolving, please store at -20°C. Do not freeze-thaw more than three times.

## Step by Step to start a AT10025 Purification Run

1. On the **Start** screen: Click “ENTER” button to enter the HOME screen.
2. On the **HOME** screen: Click “Purification” icon to start a purification run.




3. Please choose **Cat. No.**




Please click “AT”  
Then choose “AT10025”  
For iCatcher® VB DNA/RNA 250 Kit

4. Choose **Elution Vol.**



We suggest to choose **30µl or 60µl** to get higher concentration of viral DNA/RNA.


5. Insert the **Syringe** into the groove of Syringe Seat and push it to the end.



Check the **Syringe**.


**FOR RESEARCH USE ONLY**

6. Labeling , then open the lid and place the **Elution Tube** on the Elution Tube position.



Check the **Elution Tube**.


7. Insert the front protrude part of **Cartridge** into Cartridge position and press the bottom down. Then remove the foil.



Check the **Cartridge**.


**Important! Please must remove the foil before running a protocol.**

8. Insert **Column Set** into Column Set position and press into bottom.





Check the **Column Set**.

9. Place **Tip Set** on Tip Set position and press into bottom.



Check the **Tip Set**.

10. Add **5 ml** 100% EtOH into **EtOH Tube** and place on the EtOH Tube position.





Check the **EtOH Tube**.

Add **5 ml** 100% EtOH into **EtOH Tube**

11. Prepare sample as below,

- a. Add 20  $\mu$ l Proteinase K (10 mg/ml) into a 1.5 ml micro-centrifuge tube (not provided).
- b. Add 5  $\mu$ l Carrier RNA (1  $\mu$ g/ $\mu$ l) into the 1.5 ml micro-centrifuge tube.
- c. Transfer 250  $\mu$ l of serum, plasma or liquidized sample into the 1.5 ml micro-centrifuge tube.
  - For nasopharyngeal swab with transport medium, please close the cap, vortex medium with swab for 15 sec. Centrifuge and transfer 250  $\mu$ l clear supernatant . (Avoid to aspirate any debris or mucus)
- d. Close the cap, vortex for 5 sec then brief spin down  
**Important! Do not add Proteinase K directly into Buffer TVL. Mix Proteinase K with sample before adding Buffer TVL.**
- e. Add 250  $\mu$ l of Buffer TVL into the 1.5 ml micro-centrifuge tube, close the cap and vortex vigorously for 15 sec.
- f. Incubate at 56  $^{\circ}$ C for 15 min, brief spin down then transfer all lysate into the Sample Tube.  
 (For RNA virus, incubate at 25  $^{\circ}$ C for 10 min can be alternative for lysis. )
- e. Load the Sample Tube into the **Sample Tube** position of iCatcher.



Check the **Sample Tube**.  
Click "Go" to start purification.

**FOR RESEARCH USE ONLY**